

Warning:

If you experience any discomfort, immediately discontinue use.

The batteries are protected from splashing water, however should any water enter the battery packs, open them and dry for 1 day.

The heater pad circuit is insulated from water - however - do not directly subject to water such as wading in rivers.

Dispose of used batteries properly.

Do not throw batteries into an open fire as there is a risk of explosion.

Check your feet regularly for reddening of the skin. Too high temperatures over prolonged periods can lead to burns and skin irritation.

INSTRUCTIONS FOR USE OF COZY FEET**Introduction:**

By purchasing this pair of COZY FEET in-shoe warmers, you have bought a high quality product. Please read the instructions carefully before using this device.

Our feet are particularly susceptible to getting cold because they cool down more quickly than the rest of the body.

These COZY FEET are designed to help bring feet back to their correct body temperature.

COZY FEET in-shoe warmers will warm up to a safe, comfortable temperature just above body heat

Installation:

Place the heater pad inside the sole of each shoe or boot. The heater pad must not directly contact skin. The user must wear socks to maintain a safe barrier between the skin and the heater pad.